

Cat. No. 0233001 Oar Leathers and Buttons INSTALLATION INSTRUCTIONS

Oar Leathers and buttons are installed on oars to prevent them from being chafed by oarlock horns. Installation is as follows:

1. Mark position of the oarlock on each oar when in rowing position.
2. Lay one end of the leather along oar -- centered on the oarlock mark. Then tack it down with brass or monel brads.
3. Wrap leather around oar, mark where tacked down ends meet, and trim off excess leather. Tack down with ends butted firmly against each other.
4. Position button on top of installed leather so that its edge meets the inboard edge of the leather(see diagram).
5. Tack on end down. Then tack around oar and trim off the excess so that the ends are butted firmly against each other.

