

PERKO®

CAT. NO. 0179 FOG BELL INSTALLATION INSTRUCTIONS

NOTE: The supporting arm assembly is furnished disassembled for ease of installation. Install as follows:

1. After selection of mounting location, position and install the top bracket (Part 1).*
2. Attach lower mounting bracket (Part 2) to top bracket by inserting eye-bolt clapper assembly (Part 3) and securing with acorn nut (Part 4) as illustrated.
3. Taking care that both brackets are aligned, fasten lower bracket (Part 2) to mounting surface.*
4. Remove eye-bolt clapper assembly and acorn nut (Parts 3 & 4).
5. Insert eye-bolt clapper assembly (Part 3) thru inside of bell, securing to supporting arm assembly with acorn nut (Part 4).

* Due to variations in installation, mounting screws are not provided. Installation will require four No. 14 wood screws or 1/4 inch diameter machine screws.

0179INS1
1/05

PERKO, INC.
16490 N W. 13th Avenue
Miami, FL 33169-5707
www.perko.com

